

Update via network


Following conditions:

1. PC with Windows OS
2. Home network with router
3. On the PC is the STB Daemon tool installed

Install STBDaemon on PC and start




Select (Browse...) PATH and folder (Sharing folder) where firmware is stored




Connecting receivers with [network cable](#) (incl. routers),

PC ↔ router ↔ HD5000 Combo Plus

Enter network parameters in the menu of the receiver (**IP settings**), or select DHCP (parameters automatically from router) .



In the menu choose with blue key **firmware Update** , enter PC IP address and press OK .



A file list message pop up (in receiver frontdisplay FILE LOADER) choose the firmware, and start the firmware update with OK.

